



Contactless reader CANCrocodile



CANCrocodile is used in vehicle telematics and GPS tracking system for safe contactless data gathering from automotive buses T-CAN and M-CAN.

- CAN j1939 bus data reading with no damage to wire insulation.
- ✓ Protecting vehicle electronic systems against active requests from telematics unit.
- Saving warranty for a vehicle.



Easy installation - no special tools needed.

- 1. Open CANCrocodile case.
- 2. Put CAN H and CAN L wires along the marks on reading surface.
- 3. Close the case until click and connect CANCrocodile wires to telematics unit's CAN-port and electrical network of vehicle.









12/24 - 12/24 V, basic version

Models:

12/24 A++ - 12/24 V, current consumption in sleep mode is 1/0,5 mA

L - output cable length

CAN ROCODILE U12/24 LO.7 CS

0.7 - 0,7 m, basic version

2 - 2,0 m

C - output cable ending:

S - connector, basic version

W - bare wires

C - crimped wires